



Machine	Explode	Code	Description
CU479 - Buffalo 600 Series Chip Scuttle	1	AT067	Supply Cable With UK Plug
CU479 - Buffalo 600 Series Chip Scuttle	1	AT002	Supply Cable With EU Plug
CU479 - Buffalo 600 Series Chip Scuttle	2	AT003	Cable Gland
CU479 - Buffalo 600 Series Chip Scuttle	3	AT005	Feet
CU479 - Buffalo 600 Series Chip Scuttle	4	AT004	Porcelain Terminal
CU479 - Buffalo 600 Series Chip Scuttle	5	AT006	Logo Buffalo
CU479 - Buffalo 600 Series Chip Scuttle	6	AT007	Green Signal Lamp
CU479 - Buffalo 600 Series Chip Scuttle	7	AT008	Knob
CU479 - Buffalo 600 Series Chip Scuttle	8	AT068	Panel Label 0-I
CU479 - Buffalo 600 Series Chip Scuttle	9	AT010	On/Off Switch
CU479 - Buffalo 600 Series Chip Scuttle	10	AT069	Perforated Tank Inner Sheet
CU479 - Buffalo 600 Series Chip Scuttle	11	AT070	Porcelain Heater
CU479 - Buffalo 600 Series Chip Scuttle	12	AT071	Internal Wiring Group
CU479 - Buffalo 600 Series Chip Scuttle	N/A	AP953	Joining Bar