














Machine	Explode	Code	Description
Buffalo Bistro Single Contact Grill	1		Apron
Buffalo Bistro Single Contact Grill	2		Top Cover Plate
Buffalo Bistro Single Contact Grill	3		Rear Cover Plate
Buffalo Bistro Single Contact Grill	4		Lower Heat Pipe Cover Plate
Buffalo Bistro Single Contact Grill	5		Bottom Sealing Plate
Buffalo Bistro Single Contact Grill	6		Oil Box
Buffalo Bistro Single Contact Grill	7	AS322	Handle
Buffalo Bistro Single Contact Grill	8	AS325	Thermostat
Buffalo Bistro Single Contact Grill	9	AS328	Upper Heater
Buffalo Bistro Single Contact Grill	10	AS329	Lower Heater
Buffalo Bistro Single Contact Grill	11		Top Grill (Ribbed) for CU600
Buffalo Bistro Single Contact Grill	12		Bottom Grill (Ribbed) for CU600
Buffalo Bistro Single Contact Grill	11		Top Grill (Flat) for CU601
Buffalo Bistro Single Contact Grill	12		Bottom Grill (Flat) for CU601
Buffalo Bistro Single Contact Grill	13	AS332	Indicator Light
Buffalo Bistro Single Contact Grill	14	AS333	Switch
Buffalo Bistro Single Contact Grill	15	AS334	Hi-Limit
Buffalo Bistro Single Contact Grill	16		Guard Pipe
Buffalo Bistro Single Contact Grill	17		Terminal
Buffalo Bistro Single Contact Grill	18		UK Power Cord
Buffalo Bistro Single Contact Grill	19	AS337	Black Rubber Feet (set 4)