









Machine	Explode	Code	Description
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	1		Top Cover
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	2		Insulation
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	3		Toaster Top Cover
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	4	AK552	Plug & Wire
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	5		Back Panel
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	6		Main Body
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	7		Insulation
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	8		Insulation Sheet
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	9		About Cover Plate
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	10	AH364	Fixation 1
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	11	N125	Thermostat
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	12	AD585	Light
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	13	AH040	Switch
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	14	AK361	Dial
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	15	AE662	Heating Element
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	16	AE657	Rack
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	17	AE658	Handle
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	18	N287	Feet
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	19	AE659	Crumb Tray
DB177 - Buffalo Salamander Grill - 2.8kW (Top Only)	20	AE660	Tray

