












Machine	Explode	Code	Description
FU476 - Buffalo Spice Grinder	1	AS066	Cup Lid
FU476 - Buffalo Spice Grinder	2	AS067	Clear Cover
FU476 - Buffalo Spice Grinder	3	AS068	Seal Ring
FU476 - Buffalo Spice Grinder	4	AS069	Blade
FU476 - Buffalo Spice Grinder	5	AS070	Spacer
FU476 - Buffalo Spice Grinder	6	AS071	Grinding Cup
FU476 - Buffalo Spice Grinder	7	AS072	Driven Wheel
FU476 - Buffalo Spice Grinder	8	AS073	Rubber Sheath
FU476 - Buffalo Spice Grinder	9	AS074	Switch Panel
FU476 - Buffalo Spice Grinder	10		Housing
FU476 - Buffalo Spice Grinder	11		Wire Cover
FU476 - Buffalo Spice Grinder	12	AS075	Button
FU476 - Buffalo Spice Grinder	13	AS076	Spring
FU476 - Buffalo Spice Grinder	14		Switch Box Cover
FU476 - Buffalo Spice Grinder	15	AS077	Switch Circuit Board
FU476 - Buffalo Spice Grinder	16		Switch Box Base
FU476 - Buffalo Spice Grinder	17	AS078	Drive Wheel
FU476 - Buffalo Spice Grinder	18		Touch Stand
FU476 - Buffalo Spice Grinder	19		Spring
FU476 - Buffalo Spice Grinder	20		Main Seat
FU476 - Buffalo Spice Grinder	21	AP335	Micro Switch
FU476 - Buffalo Spice Grinder	22		Micro Switch Seat
FU476 - Buffalo Spice Grinder	23		Power Cord
FU476 - Buffalo Spice Grinder	24		Motor Bracket
FU476 - Buffalo Spice Grinder	25		Pressing Plate
FU476 - Buffalo Spice Grinder	26		Motor Shockproof Glue
FU476 - Buffalo Spice Grinder	27	AS079	Circuit Board
FU476 - Buffalo Spice Grinder	28		Motor
FU476 - Buffalo Spice Grinder	29		Rubber Hose
FU476 - Buffalo Spice Grinder	30		Base
FU476 - Buffalo Spice Grinder	31	AS080	Feet (set 4)
FU476 - Buffalo Spice Grinder	32	AS081	Brush